

# Mountain Top® Eloxclean


Instruction manual




# Eloxclean

---


Instructions. **(fig. 1 - 3).**



**(Fig. 1)** Apply a few drops of the Elox-cleaner on a dry cloth



**(Fig. 2)** Gently clean the surface with the Elox-cleaner. Do only put light pressure on the surface. Only polish the surface parallel to the length of the profile. Only polish very carefully, if it is overdone you will damage the surface.



**(Fig. 3)** After the surface has been polished, remove excessive polishing cream. The Elox-cleaner will leave a protective layer on the profile which has to be renewed from time to time.



Customer Service	+45 4810 2950 (08:00 - 16:00 CET)
Fax	+45 4810 2960
Support	<a href="mailto:info@mountaintop.dk">info@mountaintop.dk</a>
Website	<a href="http://www.mountaintop.dk">www.mountaintop.dk</a>
Address	Pedersholmparken 10, 3600 Frederikssund, Denmark