


# AEROKLAS - CARGO DIVIDER

## INSTALLATION MANUAL AEROKLAS CARGO DIVIDER 2022

Fit Time: 10 mins



**Aeroklas Factory (Rayong)**  
111/1, 111/10 Moo 2,  
Tambol Makhmku,  
Amphur Nikompattana,  
Rayong 21180 Thailand.  
Tel: +66-3889-3599-610

**Aeroklas Office (Bangna)**  
62 Soi Bangna-Trad 25,  
Bangna-Trad Rd., Bangna,  
Bangkok 10260 Thailand.  
Tel: +66-2744-3020

[AEROKLAS.COM](http://AEROKLAS.COM)

**EXPLODE VIEW**

(NEW) PLASTIC SUPPORT PLATE **I** x2

LOBE KNOBS WITH THREADED STUD M8X20 (50 mm.) **J** x4

BRACKET SUPPORT AEROKLAS DIVIDER 2022 **H** x2

NOTE: THE LHS IS THE SAME AS THE RHS SIDE.

**TIGHTEN**

**SECTION VIEW**

**TIGHTEN KNOB SCREW TO CLAMP BRACKET WITH CMS BY HAND**

NOTE: THE LHS IS THE SAME AS THE RHS SIDE.

**NEXT STEP**

**MAIN BODY AEROKLAS DIVIDER 2022**  
**A** x1

**ASSEMBLE MAIN BODY DIVIDER WITH BRACKET SLIDE**

**MUSHROOM HEAD SQUARE NECK BOLTS SS304 M8X45 mm.**  
**K** x2

**TOP VIEW**

**ASSEMBLE MAIN BODY DIVIDER WITH BRACKET SLIDE**

NOTE: THE LHS IS THE SAME AS THE RHS SIDE.